

Chassis number:

Model: 735i M62 SAL

## Body/electrics

- Check the lights.
- Check the instrument and display lighting and the heater blower.
- Check the horn, headlight flasher and hazard warning flashers.
- Seat belts: check condition of belts, function of reels, belt locks and belt catches.
- Battery
  - Check battery acid level and state of charge (Magic Eye).
  - If necessary: recharge battery.<sup>1</sup>
- Heating or air conditioning: renew micro-/activated charcoal filter. (If vehicle is used in very dusty conditions, renew filter more frequently.)<sup>1\*</sup>
- Inspect the entire body - except cavities - for corrosion.

## Engine compartment

- Brief diagnostic test
- Change engine oil and renew filter element. **(7,5 l)**
- Check coolant level. When refilling: check concentration.
- Note: change the coolant after max. 4 years ( filling quantity as required).<sup>1</sup>
- Reset Service Indicator in accordance with manufacturer's directives.
- Windscreen washer and intensive cleaning system: check fluid levels and top up if necessary.
- Power steering reservoir: check oil level, add oil if necessary.
- Brake hydraulics: check fluid level and top up if necessary.
- Brake fluid: renew according to Service Interval indicator display, but not later than after 2 years.<sup>1</sup>
- Renew the spark plugs.
- Intake air silencer: renew air cleaner element (renew more frequently in very dusty conditions).

## Running gear

- Brake pads
  - Measure brake pad thickness with measuring gauge.
  - If pads have to be renewed: clean caliper apertures. Check brake disc thickness and surfaces. If rear brake pads are renewed: check parking brake linings. Grease centering spigot if car is fitted with light-alloy wheels.<sup>1</sup>
- Steering components: check for freedom from play, leaks, damage and wear.
- Underbody including all visible parts: check for damage, leaks and corrosion.
- Brake lines and unions: inspect for leaks, damage and incorrect positioning.
- Parking brake: check lever travel and adjust according to manufacturer's directives if necessary.
- Tyres: check pressures and correct if necessary (including spare wheel), check external condition, tread depth and tread wear

## Final check

- O Check items affecting road safety.
  - Bed down pads for parking brake
  - steering or power steering
  - automatic transmission
  - shock absorbers
  - Check telltale
  - Check Control
  
- 1 invoiced as an additional item
- 1\* invoiced as an additional item unless standard equipment on car
- 2 invoiced as an additional item (comply with national legislation)